

SCM SIM Card Reader Professional

Manage and edit the data on your SIM Card.

The SCM SIM Card Reader is suitable for all types of mobile phone and GSM networks.

The stick allows you to

- edit and update
- transfer and copy
- Import and export
- archive and restore
- automatically internationalize
- produce clear print-outs
- program special functions

CONTENT

uTrust Token Standard Reader black

SIM Adapter schwarz for Nano SIM to SIM ID-000

SIM Adapter schwarz for Micro SIM to SIM ID-000

Software CHIPDRIVE® Smartcard Commander pro on CD (Deutsch, English, Italiano)

System requirements

Free USB port (USB 2.0, 3.0)

Microsoft Windows XP / Vista / 7 / 8 / 8.1 / 10(32/64bit)

Mini-SIM ID-000

Article No.

775-2025-05